

CABINET PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00 (White) (Black) (Stainless Steel) Sparkle)



CABINET PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00 (White) (Black) (Stainless Steel) Sparkle)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.	DESCRIPTION
Folio RE	W10353988 W10343810 Dwing May D-IT-YOU EPAIR MA 677969 W10300065 2166108 W10339257 W10353930 W10353932	Do-It-Yourself Manual Ref./Fzr.  Hinge (Top) Roller, Front (2) Endcap, Grille White	\	489427 549193 489497 2254618 2183852 8281265	Screw Tube Clamp Screw Clamp, Cord Screw Hinge, Center Shim, Hinge Center Screw Hinge Butt Fitting, Water Tube (NOT SERVICED) Hole Plug (6) White Black Grey Corner Filler (2) White Black	20 21 23 24 25	Grey Washer, Plain Washer, Nylon Cover, Hinge White RS White LS Black RS Black LS Grey RS Grey LS Rail, Center (NOT SERVICED) Cover, Toe Grille Hinge White Black

# **LINER PARTS**




# **LINER PARTS**

For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00 (White) (Black) (Stainless Steel) Sparkle)

IIIus No.		DESCRIPTION
		Line (Alexa)
1		Liner (Not A Serviceable Part)
2	2197380	Grommet (2)
2	2254360	Gasket, Evaporator
		Cover (2)
4	W10352689	Electronic Control
5	W10381575	Thermostat Tube Barrier
6	W10336009	Screw Cup
7	W10318068	Wire Assembly,
		Control Box
8	2162085	Socket, Light
9	W10339203	Water Tube Cover
10	2315539	
11 12	2200509 W10316941	
13	W10310941 W10343913	Thermostat Assembly
10	W 100-0010	(Includes #5)
14	W10300161	Shield, Light
15	488208	Screw
16	W10305173	Cover, Evaporator Light Bulb (2)
17	W10311528	Light Bulb (2)
18	W10348614	Cover, Light
19	1118894	Rocker Arm Switch
20	W10339627	Wire Assembly,
		Frzr. Compartment
		(Includes
		Illus. 28)
21	W10305175	Cover, Air
22	W402E6040	Diffuser
23	W10356940 W10305174	Knob, Thermostat Air Tower
24	W10303174 W10376137	Air Diffuser,
		Bottom
		Assembly
25	2210509	
26	W10310927	Air Diffuser Cup
27	488208	
28 29	W10392132 W10321162	
29	W 10321162	Bracket, Fan Motor
31	W10396926	
32	489442	Screw
33	489478	
34	2254454	Bracket
		Evap. Fan, Rear
35	941839	Hole Plug
		(Icemaker)


# **SHELF PARTS**

For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00 (White) (Black) (Stainless Steel) Sparkle)




Illus No.		DESCRIPTION
1	W10486289	Shelf, Glass
2	W10308861	Pan, Crisper
3	W10404446	
4	W10384386	Shelf, Wire FC
5	W10404450	Track Rail RH
6	W10404449	Track Rail LH
7	W10308849	Pan, Meat
8	W10373943	Pan Crisper 12"

9 W10130299 Shelf Cup FC




FREEZER DOOR PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00
(White) (Black) (Stainless Steel) Sparkle)



IIIus No.		DESCRIPTION	Illus. No.	. Part No.	DESCRIPTION	IIIus No		DESCRIPTION
1		Freezer Door	5		Hole Plug,	8	W10308875	Trim, Door
		(Includes			Hinge Sleeve			Shelf (2)
		Illus. 4 & 6)		2212648	White	9		Nameplate
	W10406259	White		2212651	Black		W10481434	White
	W10406261	Black		2254517	Grey		W10481433	Shadow Grey
	W10406263	Stainless Steel	6		Door Gasket,	10		Handle
	W10406262				Magnetic		W10498429	White
2	2189202	Bracket, Door		2214967	Mist Beige		W10498430	Black
		Stop		2214969	Black		W10498431	Titanium Sparkle
3	489357	Screw		W10171479	Grey	11	W10338485	EndCap Trim LS
4	W10334042	Thimble	7	489276	Screw	12	690046	Set Screw
						13	W10170540	Screw
						l 14	W10308871	Endcap Trim RS

REFRIGERATOR DOOR PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00
(White) (Black) (Stainless Steel) Sparkle)




# **REFRIGERATOR DOOR PARTS**

For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00 (White) (Black) (Stainless Steel) Sparkle)

Illus No.		DESCRIPTION
1		Refrigerator Door
		(Includes
	W40406220	Illus. 4 & 6)
	W10406239 W10406240	White Black
	W10406240 W10406244	
	W10406242	
2	2189202	Bracket, Door
_		Stop
3	489276	•
4	W10334042	Thimble
5		Hole Plug,
		Hinge Sleeve
	2212648	
	2212651	
6	2254517	Grey Door Gasket,
0		Magnetic
	2202875	Mist Beige
	2202882	
	W10171475	Grey
7	W10308809	
8	W10308868	Bin Long
9		Handle
	W10498429	
	W10498430	
40	W10498431	
10 11	W10308869 W10308845	Bin Med
12	W10308843	Can Caddy Utility Flip Lid
13	W10308874	Trim, Door Shelf
14	489357	
	W10338485	
	W10308871	
17	W10170540	Screw
18	690046	Set Screw

UNIT PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00
(White) (Black) (Stainless Steel) Sparkle)



UNIT PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00
(White) (Black) (Stainless Steel) Sparkle)

IIIus No.		DESCRIPTION	Illus No		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10300118		15		Start–Device Combination	Follo	wing Pa	arts Not Illustrated
2	W/1031/107	Mounting Bracket, Evap			(Start Relay and			Parts Not Included
3		Condenser			Overload)	l	1	
4		Heater, Defrost		W10194431	Production		978025	Valve, Access
5		Evaporator Assy.		W10194431				(1/4")
6	8533961		16		Condenser Grommet		978026	Valve, Access
7		Shield, Heat	17	2150304				(5/16")
8		Drain Valve	18	2179826	Rivet		978027	Valve, Access
9	2263990		19	W10466213				(3/8")
10		Clip, Condenser	20		Strap, Compressor		978028	Valve, Access
11	W10349515	Cover, Condenser	21	3400518			070000	(1/2")
	11// 000000	Bottom	22	14404	Drier		978029	Valve, Access
12	W10296661				Production		070000	(5/8")
13	0004047	Capacitor	00	W10143759			978030	Valve, Access
		Production	23	W10410814	Wire Assembly		976764	(3/4") Valve, Access
14	2264017	Grommet	24	W10139483	Unit Ean Blade		070704	(3/16")
14	10835003	Production	25		Tube, Suction			(3/10)
	1100826		26		Tube, Process			
	1100020	OCIVIOC	27	488500		REF	RIGERA	NT CHARGE
			28		Compressor	l <del></del>		
					(Includes Items			4.0 Ozs.
					13, 14, 15 & 22)			(R134A)
			29	2315541				
			30	2188874	Motor, Condenser			

OPTIONAL PARTS
For Models: WRT351SFYW00, WRT351SFYB00, WRT351SFYF00, WRT351SFYM00
(White) (Black) (Stainless Steel) Sparkle)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION		
Parts Not Illustrated and Optional Parts (Not Included)	Customer Touch-Up Material  *350942 Primer, White	ICE MAKER FIELD INSTALLABLE		
978941 Insulation, Fiberglass (63–1/2" x 35–1/2" x 2–5/8") 212643 Sealer, Gum	(12 Oz. Spray Can)  *350939 Enamel, Black (12 Oz. Spray Can)  *350930 Enamel, White (12 Oz. Spray Can)	2155469 ECKMF94  TORX SCREW WRENCH		
(4 Feet) 479502 Tape, Vinyl (3/4" x 108") W10395148 Kit, Door Reversal 876305 Kit, Insulation (14 Pcs.	*4392901 Enamel, Biscuit (12 Oz. Spray Can) 72017 Brush Touch-Up Kit (White) 72032 Brush Touch-Up Kit (Black)	1117510 Torx Key		
3" x 24" x 48") 876370 Kit, Insulation (2 Pcs. 3" x 24 " x 48")	4392899 Brush Touch-Up Kit (Biscuit)  Refinishing Material			
876029 Kit, Foam Slab (30" x 32-1/2" x 1-1/2") 505587 Sealer, Mastic (1 Qt.)	799344 Enamel, White (1 Qt. Uncut) 4392900 Enamel, Biscuit (1 Qt. Uncut)			
511873 Touch-Up, White Porcelain (2 Oz.) 542638 Grease, Silicone	833938 Kit, Terminal Connector			
(1/2 Oz.) 542639 Cement, Alumilastic	* Important: The spray paint is not to be used where the paint may make contact with the door			
(1–1/4 Oz.) 606755 Bag, Insulation (36–5/8" x 46") 503695 Cork Sealer	gaskets.			

(1/4 Pound)